

Jacuzzi Circuit Board Replacement Chart for J-300 Series



Led System Controls

Temperature displays in RED numbers. Topside control may have as few as four buttons or as many as six. Used in J-310, J-320, J-330 and J-340 in 2002-2003 and J-315, J-325, J-335 and J-345 from 2004 to 2012. Also used in J-355, J-365, J-375 from 2007 to 2012.



Spa Model	Newest Circuit Board	Replaces These Numbers	Model Year
J-310	6600-724	6600-086 - 6600-286 - 6600-044	2002-2003
J-315	6600-724	6600-086 - 6600-286 - 6600-044	2004 to 2012
J-320	6600-726	6600-088 - 6600-288 - 6000-167	2002-2003
J-325	6600-724	6600-086 - 6600-286 - 6600-044	2004 and 2008 to 2012
J-325	6600-726	6600-088 - 6600-288 - 6000-167	2005-2007
J-330	6600-726	6600-088 - 6600-288 - 6000-167	2002-2003
J-335	6600-726	6600-088 - 6600-288 - 6000-167	2004-2012
J-340	6600-726	6600-088 - 6600-288 - 6000-167	2002-2003
J-345	6600-726	6600-088 - 6600-288 - 6000-167	2004-2012
J-355	6600-726	6600-088 - 6600-288 - 6000-167	2007-2012
J-365	6600-726	6600-088 - 6600-288 - 6000-167	2007-2012
J-375	6600-726	6600-088 - 6600-288 - 6000-167	2007-2012

Matching
Topside
Controls



LCD System Controls

Temperature displays in Black numbers. Topside control has 10 buttons. Used in J-350, J-360, J-370 and J-380 in 2002-2003 and J-355, J-365, J-375 and J-385 from 2004 to 2006.

Spa Model	Newest Circuit Board	Replaces These Numbers	Model Year
J-350	6600-730	6600-092 - 6600-180	2002-2003
J-360	6600-730	6600-092 - 6600-180	2002-2003
J-370	6600-730	6600-092 - 6600-180	2002-2003
J-380	6600-101	6600-092 - 6600-180	2002-2003
J-355	6600-730	6600-092 - 6600-180	2004-2006
J-365	6600-730	6600-092 - 6600-180	2004-2006
J-375	6600-730	6600-092 - 6600-180	2004-2006
J-385	6600-101	6600-092 - 6600-180	2002-2006

Matching
Topside
Control

