



Filling your hot tub.

Congratulations! Your new Jacuzzi Premium hot tub will provide you with years of enjoyment and relaxation.

Filling a new hot tub can trap air in the internal plumbing. This can cause air locks within the system, which will prohibit your hot tub from heating. A flow message may appear on the control panel readout. To avoid air locks please follow these step-by-step instructions.

Step 1

Remove the filter housing as shown here. Place filter housing outside of the hot tub.

Stand at the edge of your hot tub looking down into the filter housing. Visually locate right filter and go to Step 2.



Step 2

Remove right filter by turning counterclockwise. Place filter outside the hot tub.

Locate your water source; attach a garden hose and position hose nozzle over filter housing of hot tub. Move on to Step 3.



Step 3

Insert garden hose into right filter housing inlet. Fill the tub while holding hose firmly in place.


Continue filling through filter housing inlet until water level has covered the filter inlets. The water level should be approximately 3 inches above the hose nozzle.



Step 4

When water level exceeds filter inlets, then remove second filter (left).

Locate ozone jet (right). Ozone jet is located in the footwell of hot tub and is the smallest jet within the hot tub.



Step 5

Place garden hose directly over ozone jet as pictured (right) firmly hold in place until all air has been expelled through the left filter housing inlet.

This should take approximately 30 seconds. Once this step has been completed **resume Step 3** by filling through right filter housing inlet.



Please refer to pre-delivery guide and/or owner's manual for complete instructions for proper set-up, maintenance and use.